

FIG. 1






FIG. 2






FIG. 3






FIG. 4






FIG. 5




FIG. 6




FIG. 7







FIG. 8 Prior Art



Actuator for Disk Device Tetsuya Takashima Serial No. 10/088,470 Replacement Sheet 7/10



FIG. 9 Prior Art




FIG. 10 Prior Art






FIG. 11 Prior Art







FIG. 12 Prior Art



Actuator for Disk Device Tetsuya Takashima Serial No. 10/088,470 Replacement Sheet 10/10



FIG. 13 Prior Art

